

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator John Yuronka	8. Farm or Lease Name Lankford
3. Address of Operator 807 Petroleum Bldg., Midland, TX 79701	9. Well No. 4
4. Location of Well UNIT LETTER <u>E</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>25</u> TOWNSHIP <u>23-S</u> RANGE <u>36-E</u> N.M.P.M.	10. Field and Pool, or Wildcat Langlie Mattix SR-Q-64
15. Elevation (Show whether DF, RT, GR, etc.) 3358' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following work is to be performed to shut-off water production:

- 1) Pull Rods, Pump, and Tubing
- 2) Set Drillable Bridge Plug @ 3500'
- 3) Spot Sand up to 3460'
- 4) Squeeze perforations @ 3416', 3446', and 3450' w/75 Sacks w/cement retainer @ 3375'
- 5) Drill out cement, sand, and bridge plug w/bit and casing scraper
- 6) Reperforate all holes
- 7) Treat w/500 gals. Xylene, 1 Bbl. Paracheck 120, and 2,800 gals. of 15% NeFe acid under a Packer w/Ball Sealers
- 8) Place well back on production

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Yuronka TITLE Authorized Agent DATE November 20, 1987

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE NOV 24 1987

CONDITIONS OF APPROVAL, IF ANY: