

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO.  
30-025-32501

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

R. R. Sims A

8. Well No.

#7

9. Pool name or Wildcat

ABO, Drinkard, Blinebry

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Texaco Exploration & Production, Inc.

3. Address of Operator

P. O. Box 3109, Midland, Texas 79702

4. Well Location

Unit Letter M: 825 feet from the South line and 825 feet from the West line

Section 4 Township 23-S Range 37-E NMPM Lea County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Bull head squeeze Perfs w/100 sx cmt (ABO, Drinkard, Blinebry)
2. Cut 2 3/8" tbg @ 2900', spot 50 sx plug (Stub Plug) Tag @ 2605'
3. Perf 6 holes @ 2600', unable to pump into Perfs, spot 50 sx plug 2600'-2300' Tag @ 2278' (B-Salt)
4. Displace hole w/MLF 9.5# brine w/25# gel p/BBL
5. Spot 40 sx plug 1250'-1050' (9 5/8" shoe) Tag @ 1035'
6. Spot 20 sx 60' to surface
7. Install dry hole marker 8/29/00

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Fely Abalos TITLE VICE-PRESIDENT DATE 8/29/00

Type or print name FELY ABALOS Telephone No. (915) 683-4996  
(This space for State use)

APPROVED BY [Signature] TITLE FD Rep DATE 2-22-02  
Conditions of approval, if any:

GWW

