

March 30, 1999

Well Stabilizing

Casing Psig: 950 @ 9:00 AM.

Tubing Psig: 470 @ 9:00 AM.

March 31, 1999

Well Stabilizing

Casing Psig: 950 @ 9:00 AM.

Tubing Psig: 470 @ 9:00 AM.

April 1, 1999

Well Stabilizing

Casing Psig: 950 @ 9:00 AM.

Tubing Psig: 470 @ 9:00 AM.

April 2, 1999

Well Stabilizing

Casing Psig: 940 @ 9:00 AM.

Tubing Psig: 480 @ 9:00 AM.

April 3, 1999

Well Stabilizing

Casing Psig: 940 @ 9:00 AM.

Tubing Psig: 460 @ 9:00 AM.

April 4, 1999

Well Stabilizing

Casing Psig: 940 @ 10:00 AM.

Tubing Psig: 460 @ 10:00 AM.

April 5, 1999

Well on test

Casing Psig: 940 @ 10:00 AM.

Tubing Psig: 470 @ 10:00 AM.

April 6, 1999

Well on test

Casing Psig: 940 @ 10:00 AM.

Tubing Psig: 460 @ 10:00 AM.

April 7, 1999

Well on test

Casing Psig: 940 @ 10:00 AM.

Tubing Psig: 460 @ 10:00 AM.