

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
COMMISSION

SUBMIT IN TRIPLICATE*
(Other instructions
reverse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-061936-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Cotton Draw Unit

8. FARM OR LEASE NAME

Cotton Draw Unit

9. WELL NO.

34

10. FIELD AND POOL, OR WILDCAT

Paduca Deleware

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 9, T-~~23~~²⁵-S, R-32-E

12. COUNTY OR PARISH 13. STATE

Lea

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Texaco Inc.

3. ADDRESS OF OPERATOR

P.O. Box 730, Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface

330' FSL & FEL (Unit Letter P)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3456' DF

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) MIRU PU.
- 2) GIH w/2-1/16" tbg. Ld csg w/salt gel mud consisting of a 10# brine containing 25# gel/bbl.
- 3) Spt 10 sx cmt inside 2-7/8" csg from top of CIBP @ 4500' to 4200'.
- 4) RU WL trk. Run free pt. survey. Cut 2-7/8" csg above free pt., est. to be approx. 1200'. POH w/csg.
- 5) GIH w/2-1/16" tbg to top of cut-off csg. Ld hle w/salt gel mud.
- 6) Spt 30 sx cmt across 2-7/8" csg stub. (Vol. of cmt calc. to cover 50' inside 2-7/8" csg and 50' inside 6-3/4" OH). SION.
- 7) Tag cmt plug.
- 8) Spt 40 sx across 7-5/8" csg shoe. (Vol of cmt calc. to cover 50' inside 6-3/4" OH and 50' inside 7-5/8" csg).
- 9) Spt 10' plug at surf.
- 10) Cut off WH. Install marker.
- 11) RD PU. Cln locn.

VERBAL APPROVAL BY SHANNON SHAW

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Area Manager

DATE

11/13/89

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

11-27-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side