

UNITED STATES
DEPARTMENT OF THE INTERIORSUBMIT IN TRIPL
(Other instructions
verse side)TE*
re-Form approved.
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY

HOBBS OFFICE O.C.C.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to an existing reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

LC-062300

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

NONE

7. UNIT AGREEMENT NAME

Cotton Draw Unit

8. FARM OR LEASE NAME

Cotton Draw Unit

9. WELL NO.

20

10. FIELD AND POOL, OR WILDCAT

Paduca Delaware

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 15, T-25-S, R-32-E

12. COUNTY OR PARISH

Lea

13. STATE

N. M.

1.

OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

TEXACO Inc.

3. ADDRESS OF OPERATOR

P. O. Box 728 - Hobbs, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surfaceWell located 660' from the North Line, and 660' from the West
Line of Section 15, T-25-S, R-32-E, Lea County, New Mexico.

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3452' (D. F.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☒
☐
☐

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

☐
☐
☐
☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)☐
☐
☐

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to do the following work on subject well:

1. Tag bottom with tubing, if bottom below 4711', skip items 2 & 3.
2. Using pump truck, mud tank, tubing with saw-toothed pup-joint, & tongs to rotate, reverse circulate hole clean to 4745' with water.
3. Swab test well, if results unsuccessful, proceed to item 4.
4. Pull tubing and frac with 2500 gallons refined oil, 2500 pounds of sand, and flush with 100 bbls lease crude.
5. Swab well, recover load oil, Test, and place well on production.

18. I hereby certify that the foregoing is true and correct

SIGNED

Dan Gillett

TITLE

Assistant District

DATE

November 29, 1966

(This space for Federal or State office use)

Superintendent

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side