

yd #1 - Jalmat
CONTINUED FROM PAGE 1

01-15-80 Tagged cmt. plug @ 1355'. Spotted 15 sx NE cmt. @ 1355'. Pld tbg to 1150'. Spotted 50 sx NE cement @ 1150'. Spotted 100 sx NE cmt. 130'. WOC 5 hrs. Tagged cement @ 24'. Lay down all tbg. Removed BOP & flange back to top of 13 3/8" csg. Pumped 5 sx cmt. Circ to surface.

All pits have been filled and location has been levelled and cleared of junk