

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other Instructions on Reverse Side)

Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

LC 032581 (6)
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Continental Oil Company

3. ADDRESS OF OPERATOR

Box 460, Hobbs, N. Mex. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

1650' FNL & 1650' FEL Sec. 25, T25S, R-36E,

Lea County, N. Mex.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3082 K B

7. UNIT AGREEMENT NAME

N M Z 71

8. FARM OR LEASE NAME

Sholes R-25

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Scarborough Gates

7 miles N. M. Z. 71

11. SEC., T., R., M., OR B.L.K. AND SURVEY OR AREA

Sec. 25, T-25S, R-36E

12. COUNTY OR PARISH

Lea

13. STATE

N. Mex.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Convert to a salt water disposal

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to convert this well to a salt water disposal well by the following method:

- 1) Squeeze perforations from 2813' to 2889'
- 2) Drill out cement plugs and retainers.
- 3) Acidize from 3,010' to 3110'
- 4) Perforate from 3012' to 3110'
- 5) Run 3" plastic lined tubing with packer, and set packer at 3110'.
- 6) Hook-up for water disposal.

* Acidize if needed to get well to take all water produced.

18. I hereby certify that the foregoing is true and correct

SIGNED M. E. Gordon

TITLE Admin Section Chief

DATE 9-16-68

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

SEP 17 1968

*See Instructions on Reverse Side

J. L. GORDON
ACTING DISTRICT ENGINEER

US 52-p Pan Am - 3, Atl-Ros-2, Chev. mid-2 File