

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CEMENT OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☐ GAS WELL ☒ OTHER ☐

1. Name of Operator
TEXACO Inc.

2. Address of Operator
P. O. Box 728 - Hobbs, New Mexico 88240

3. Location of Well
UNIT LETTER **K** **1980** FEET FROM THE **South** LINE AND **1980** FEET FROM
THE **West** LINE, SECTION **21** TOWNSHIP **24-S** RANGE **37-E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3227' (GR)

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.
-

7. Unit Agreement Name
-

8. Farm or Lease Name
J. F. Black

9. Well No.
2

10. Field and Pool, or Wildcat
Jalmit Yates Gas

12. County
Lea

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WORK ☐ ALTERING CASING ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

PULL OR ALTER CASING ☐ OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged Up.
2. Set CIBP @ 2850'. Spot 8 sx (35') cement on top of plug.
3. Ran free point. Cut 7" OD csg @ 1338' & pulled 45 joints.
4. Spot 90 sx. cement plug from 1388-1222' (166').
5. Ran free point. Cut 8-1/4" csg @ 302' & pulled 13 joints.
6. Spot 170 sx cmt plug from 360-140' (220').
7. Spot 20 sx cmt plug from 20' - surface (20').
8. Install Dry Hole Marker. Clean up. Well P&A 3-19-77.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Asst. District Supt. DATE 3-23-77

APPROVED BY *[Signature]* TITLE DATE

CONDITIONS OF APPROVAL, IF ANY:

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p>SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PRODUCTION, TO BE USED TO REPORT ON A WELL OR PLUG BACK TO A DIFFERENT RESERVOIR, USE APPLICATION FOR REPORT ON (WELL) C-101 FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p> <p>5. State Oil & Gas Lease No.</p>
<p>1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-</p> <p>2. Name of Operator TEXACO Inc.</p> <p>3. Address of Operator P.O. Box 728 Hobbs, New Mexico 88240</p> <p>4. Location of Well UNIT LETTER K 1980 FEET FROM THE South LINE AND 1980 FEET FROM West LINE, SECTION 21 TOWNSHIP 24-S RANGE 37-E N.M.P.M.</p>		<p>7. Unit Agreement Name -</p> <p>8. Farm or Lease Name J.F. Black</p> <p>9. Well No. 2</p> <p>10. Field and Pool, or Wildcat Jalmat Yates Gas</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3227' (GR)</p>		<p>12. County Lea</p>

<p>6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p> <p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>		<p>SUBSEQUENT REPORT OF:</p> <p>ALTERING CASING <input type="checkbox"/></p> <p>PLUG AND ABANDONMENT <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>
--	--	---

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 2850' with 35' (8 sx) cement on top.
2. Load hole with mud (25 sx gel per 100 bbls. water).
3. Cut and pull 7" casing at freepoint.
4. Spot 100' (40 sx) cement plug across casing stub.
5. Spot 100' (40 sx) cement plug across 8 1/4" casing shoe at 1317'.
6. Cut and pull 8 1/4" casing at freepoint.
7. Spot 100' (70 sx cement plug across casing stub.
8. Spot 100' (100 sx) cement plug across 12 1/4" casing shoe at 188'.
9. Spot 20' (20 sx) cement plug at surface.
10. Install marker and clean location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PROPOSED OPERATIONS FOR THE C-103 REPORT.

Expired 5/15/77

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Asst. Dist. Supt. DATE 11-12-76

APPROVED BY *[Signature]* TITLE Supv. DATE 11-12-76

CONDITIONS OF APPROVAL, IF ANY: