

Pulled tubing to 7300' and circulated out recovering no cement. After waiting 6 hours, checked top cement plug with tubing. Found top cement at 8340'. Layed down 2-3/8" tubing. Went in hole with 8-3/4" bit to 8340', drilled off cement to 8360'. Completed 1 AM 10th.