

C. C. FRISTOE B NCT-2 #3

1. Rigged up. Remove well head. Install BOP.
2. Set packer @ 3180'. Tested 7" casing W/500#, 5-25-83.  
Tested OK.
3. Set CIBP @ 3170'.
4. Install Well Head Equipment. Job Complete 5-26-83.

BUREAU OF LAND MANAGEMENT REPRESENTATIVE WITNESSED TEST

RECEIVED

AUG 28 1993

O.C.D.  
MOBBS OFFICE