

MUD

MUD

CIRCULATE 65 SXS CEMENT THRU PERFS AT 300°

PERFORATE 5 1/2" CASING AT 300"

SET A CEMENT RETAINER AT 1100' SQUEEZE 25 SXS CEMENT THRU PERFS AT 1225'

1164' - 7 5/8" Casing. Cemented w/550 sxs. Circulated.

PERFORATE THE 5 1/2" CASING AT 1225"

SPOT 25 SXS CEMENT 1250'-1500'

T.O.C. • 1400' (Estimated from experience)

SET A C.I.B.P. AT 2800' W/35' CEMENT ON TOP

 $2833' - 5 \frac{1}{2}$ ". 14# Casing. Cemented w/500 Sxs

CONOCO, INC.

Jack B-30 #1

1650' FNL & 990' FEL

Sec. 30, T-24S, R-37E

Lea County, NM

T.D. • 3372'