

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

AUG 13 1 15 PM '66

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator <b>Amerada Petroleum Corporation</b>		5. State Oil & Gas Lease No.
3. Address of Operator <b>P.O. Box 668 - Hobbs, New Mexico</b>		7. Unit Agreement Name <b>Langlie Mattix Woolworth Unit Tract 11</b>
4. Location of Well UNIT LETTER <b>A</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>East</b> LINE, SECTION <b>33</b> TOWNSHIP <b>24S</b> RANGE <b>37E</b> NMPM.		8. Farm or Lease Name
		9. Well No. <b>6</b>
		10. Field and Pool, or Wildcat <b>Langlie Mattix</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3206' GR</b>		12. County <b>Lea</b>

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pull rods, pump & tubing. Drill out with air from 3541' to 3644'. Run Gamma Ray Neutron log from 2144' to 3644'. Run 2-3/8" tubing set at 3600'. Acidize open hole with 500 gals. NE acid. Swab back acid water. Run rods & pump and resume production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. J. Long TITLE Asst. Dist. Supt. DATE 8-17-66

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: