

MIDLAND E & P DIVISION

WELL WORK RECOMMENDATIONS

Proposals for Well Reconditioning and Subsurface Maintenance
Workovers, Expense DD's, PB's, and Conversions

Lease: Langlie Matlix Green Unit Well No. 2-1111V
Field: Langlie Matlix Green
County: Lea State: New Mexico

RECOMMENDED PROCEDURE:

1. M.I.R.L.
2. Pull Cement lined tubing and packer.
3. Set C.I.B.P. at 3325'.
4. Set packer at 3250'.
5. Acidize with 250 gallons acid.
6. Place well on injection with packer at 3250'.