

UNIT STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLIC
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. NM-0766
2. NAME OF OPERATOR UNION TEXAS PETROLEUM CORPORATION	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 1300 Wilco Building, Midland, Texas 79701	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 750' FWL & 2310' FNL	8. FARM OR LEASE NAME Blocker
14. PERMIT NO.	9. WELL NO. 5
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3085' GR.	10. FIELD AND POOL, OR WILDCAT (Blinebry &) Justis (Tubb-Drinkard)
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 13, T-25-S, R-37-E
	12. COUNTY OR PARISH Lea
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	
(Other) <u>Commingling</u>	<u>X</u>	(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Re-enter well and pull rods and pump. (Install BOP)
2. Kill well with 10# brine and pull Blinebry and Tubb-Drinkard tubing and packer.
3. Run tubing, pump and rods.
4. Place well back on production in the commingled Blinebry and Tubb-Drinkard Zones.

(Note: Oil Conservation Commission Administrative Order No. DHC-175 granted Union Texas Petroleum Corporation permission to downhole commingle the Blinebry and Tubb-Drinkard Zones.)

18. I hereby certify that the foregoing is true and correct

SIGNED: Stanley A. Post TITLE Gas Measurement Analyst DATE 1-23-76
(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APPROVED
JAN 26 1976
Stanley A. Post