

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-229	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation		8. Farm or Lease Name Arnott Ramsay (NCT-E)
3. Address of Operator P. O. Box 670, Hobbs, NM 88240		9. Well No. 5
4. Location of well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>560</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>25S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Jalmat Gas
15. Elevation (Show whether DF, RT, GR, etc.) 3141' GL		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with production equipment. Pumped 35' cement on CIBP at 3160'. Set CIBP at 2950'. Circulate abandonment mud. Spot 35' cement on CIBP at 2950'. Spot 100' cement plug 1200'-1300'. Spot 10 sack surface plug. Set well marker, cleared and cleaned location. P&A complete 3-8-81.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. L. Pater TITLE Area Engineer DATE 3-11-81

DATE 3-11-81