

UNITED STATES
DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPLICATE*
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill, deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT TO DRILL" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

LG 032650 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

A. B. Conter "G"

9. WELL NO.

9

10. FIELD AND POOL, OR WILDCAT

Justin Ellenburger

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 24, 25S, 37E

12. COUNTY OR PARISH 13. STATE

Lee

N. Mex.

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Tidewater Oil Company

3. ADDRESS OF OPERATOR
Box 249, Hobbs, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FSL, 1980' FEL, Sec. 24, 25S, 37E.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3086 ID

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well is producing approximately 27% water. It is proposed to plug off the bottom 35' of the open hole to shut off the water as follows: Kill Ellenburger zone (Dual Ellenburger - Tabb Drinkard) with 50-50 brine water. Run 1" N-80 tubing, began reverse circulation at 7950'. Reverse to TD at 8010', lay cement plug from TD back to 7975'. Pick up 1" and W.O.C. Tag plug and lay down 1" tubing. Swab and test. Acidise with 500 gals. if necessary.

18. I hereby certify that the foregoing is true and correct

SIGNED _____

TITLE **Area Supt.**

DATE **11-17-66**

(This space for Federal or State office use)

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APPROVED
1966
G.P.P.

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations; and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

NOV 25 11 02 AM '68
NORRIS OFFICE N.C.C.