

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

| |
|--|
| 5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/> |
| 5. State Oil & Gas Lease No. B-11478 |

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|--|
| 1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- WATER INJECTION | 7. Unit Agreement Name |
| 2. Name of Operator GETTY OIL COMPANY | 8. Farm or Lease Name JUSTIS MC KEE UNIT |
| 3. Address of Operator P.O. BOX 249, HOBBS, NEW MEXICO 88240 | 9. Well No. 404 |
| 4. Location of Well UNIT LETTER A 430 FEET FROM THE NORTH LINE AND 660 FEET FROM THE EAST LINE, SECTION 25 TOWNSHIP 25 S RANGE 37 E NMPM. | 10. Field and Pool, or Wildcat JUSTIS MC KEE |
| 15. Elevation (Show whether DF, RT, GR, etc.) 3,073' D.F. | 12. County LEA |

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

| | | | |
|--|--|---|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon the subject well as follows:

1. Mud up.
2. Place a 25 sack cement plug at 7,530' and up, or set a Baker DR Plug in the Model "D" Packer at 7,530' and dump 10' cement on top of the DR Plug.
3. If 7" casing is salvaged, place a 25 sack cement plug in and out of the 7" stub.
4. Place a 10 sack cement plug at surface.
5. Erect surface marker with proper identification.

NOTE: 1. If 7" casing is not salvaged, skip Step No. 3.
2. If 7" casing is cut below 3,350', 25 sack cement plugs would be required across the tops of other potential zones.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY:

C. L. Wade

TITLE **AREA SUPERINTENDENT**

DATE **September 21, 1971**

SIGNED _____

Only Signed by
L. D. Ramsey
Area I. Supv.

TITLE _____

DATE **SEP 27 1971**

APPROVED BY _____

CONDITIONS OF APPROVAL, IF ANY:

WLG/bh

RECEIVED

SEP 27 1971

OIL CONSERVATION COMM.
HOBBS, N. M.