

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>failed to produce</b>		7. Unit Agreement Name	
2. Name of Operator <b>Burleson &amp; Huff</b>		8. Farm or Lease Name <b>Coll</b>	
3. Address of Operator <b>Box 935, Midland, Texas 79701</b>		9. Well No. <b>1</b>	
4. Location of Well UNIT LETTER <b>H</b> , <b>1980</b> FEET FROM THE <b>north</b> LINE AND <b>660</b> FEET FROM THE <b>east</b> LINE, SECTION <b>29</b> TOWNSHIP <b>25-8</b> RANGE <b>37-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Jalmat</b>	
15. Elevation (Show whether DF, RT, GR, etc.) <b>3023 D. F.</b>		12. County <b>Lea</b>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spotted 50 sax of cement over perfs from 2437-2529
2. Filled hole with mud & water
3. 10 sax cement plug in top of 9 5/8
4. Cement marker into hole, fill in cellar.

Note: Plug back depth with Halliburton 9 5/8" plug is 2540" and none of the 9 5/8" casing will be pulled.

You will be notified when the location is cleaned up for your inspection

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Lester B. Burleson</u>	TITLE <u>Partner</u>	DATE <u>12-19-69</u>
APPROVED BY <u>Nathan E. Olegg</u>	TITLE <u>INSPECTOR</u>	DATE <u>DEC 7 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		