

P. O. BOX 1880
HOBBS, NEW MEXICO 88240
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☒ well other ☐
2. NAME OF OPERATOR ARCO Oil and Gas Company
Division of Atlantic Richfield Company
3. ADDRESS OF OPERATOR
P. O. Box 1710, Hobbs, New Mexico 88240
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 660' FSL & 1980' FEL
AT TOP PROD. INTERVAL: as above
AT TOTAL DEPTH: as above
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input checked="" type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input checked="" type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>	<input type="checkbox"/>
(other)	<input type="checkbox"/>	<input type="checkbox"/>

5. LEASE
LC-034117-A
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
R. S. Crosby "A"
9. WELL NO.
1
10. FIELD OR WILDCAT NAME
Jalmat Yates Gas
11. SEC., T., R., M. OR BLK. AND SURVEY OR AREA
29-25S-37E
12. COUNTY OR PARISH
Lea
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
3025' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

RU, kill well, install BOP & POH w/compl assy. Set RBP @ 2595'. RIH w/pkr & isolate csg holes. If surface or production csg holes are found, perforate and cement squeeze holes & csg annulus. DO cmt & pressure test. Install csg annulus pressure monitoring pipe w/valves @ surface. Recover BP. Perforate additional Yates Gas zone 2595-2612, 2637-62', 2675-85' w/2 JSPF = 104 holes. RIH w/compl assy & acidize w/2000 gals 15% NEFE & flush w/2% KCL. Swab back to clean up. Remove BOP & install wellhead. Return to production same zone.

Subsurface Safety Valve: Manu. and Type

18. I hereby certify that the foregoing is true and correct

SIGNED Robert E. Ballinger TITLE Drig. Engr. DATE 3/19/85

(This space for Federal or State office use)

APPROVED BY 4-10-85 TITLE DATE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

APR 11 1964

RECEIVED