DA&S OIL WELL SERVICING

INCORPORATED

Lewis B. Burleson, Inc.
Shahan 33 No. 2

- 9/15/94 Move in, rig up, put on BOP, set tubing at 950', pump 450 sacks cement down hole, pull tubing out, shut down.
- 9/16/94 Run tubing, tag cement at 400' from surface, perforate casing at 350', circulate 120 sacks inside 7" casing and outside to surface, shut down.
- 9/21/94 Tag cement 130' down in 7", fill to surface with cement, cut off wellhead, put in marker, rig down, move off.

Class "C" Cement Ok by Jerry Sexton, O.C.D.

505-392-6591 • P.O. BOX 2545 • HOBBS, NEW MEXICO 88241