

C.L. CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-9519	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name West Dollarhide Queen Sand Unit
2. Name of Operator Sirgo-Collier, Inc.		8. Farm or Lease Name
3. Address of Operator P. O. Box 3531, Midland, Texas 79702		9. Well No. 16
4. Location of Well UNIT LETTER <u>L</u> <u>1830</u> FEET FROM THE <u>South</u> LINE AND <u>510</u> FEET FROM THE <u>West</u> LINE, SECTION <u>29</u> TOWNSHIP <u>24S</u> RANGE <u>38E</u> NMPM.		10. Field and Pool, or Wildcat Dollarhide Queen
15. Elevation (Show whether DF, RT, GR, etc.) 3164' DF		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 2-12-88 Move in and rig up Baber Well Servicing Co.
- 2-15-88 Pick up 5-1/2" retainer and run tubing in hole to 3600' and set. Squeeze 25 sacks of cement with 5 sacks on top of retainer. Rig up wireline and perforate @ 1312'. Pick up 5-1/2" retainer and run in hole to 1150' and set. Squeeze 50 sacks of cement with 5 sacks on top of retainer. Rig up wireline and perforate @ 490'. Pick up 5-1/2" retainer and run in hole to 390' and set. Squeeze 25 sacks of cement with 5 sacks on top of retainer. Dig out cellar.
- 2-16-88 Cut wellhead and set 10 sack top hole plug. Weld on plate and install P&A marker. Rig down.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Amos L. Whitely TITLE Agent DATE February 29, 1988

APPROVED BY Rosadillo TITLE OIL & GAS INSPECTOR DATE MAR 2 1988

CONDITIONS OF APPROVAL, IF ANY:

8

HCBS OFFICE  
OCD  
MAR 2 - 1988  
HCBS OFFICE