

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

JUL 17 11 54 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	B-9519

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
3. Address of Operator	9. Well No.
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER N 660 FEET FROM THE South LINE AND 1980 FEET FROM	11. Dollarhide Drinkard Unit
THE West LINE, SECTION 29 TOWNSHIP 24S RANGE 38E N.M.P.M.	12. County
15. Elevation (Show whether DF, RT, GR, etc.)	13. Unknown

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Convert to water injection

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Move in and rig up pulling unit.
- 2) Pull rods and tubing.
- 3) Run tubing and set packer.
- 4) Rig down and connect to injection system.
- After Reservoir begins to pressure up, then:
- 5) Rig up pulling unit and pull tubing and packer.
- 6) Run tubing with bit and clean out to T. D.
- 7) Pull tubing and bit.
- 8) Put tubing and set packer.
- 9) Fill annulus with inhibited fluid.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature]

TITLE District Production Mgr.

DATE 7-15-69

APPROVED BY [Signature]

TITLE SUPERVISOR DISTRICT

DATE JUL 18 1969

CONDITIONS OF APPROVAL, IF ANY: