

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SAVTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION
N. M. O. C. C.

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

JUL 17 11 54 AM '69

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-9519
7. Unit Agreement Name Polishwade Drinker
8. Farm or Lease Name Polishwade Drinker
9. Well No. 14
10. Field and Pool, or Wildcat Polishwade Drinker
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Polishwade Drinker
3. Address of Operator Polishwade Drinker
4. Location of Well UNIT LETTER D 990 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 29 TOWNSHIP 24S RANGE 38E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) Unknown

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <u>Change in water injection</u> <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Move in and up pulling unit.
- 2) Pull casing and tubing.
- 3) Set casing and set packer.
- 4) Pull down and connect to injection system.
- 5) After reservoir begins to pressure up, then:
- 6) Run up pulling unit and pull tubing and packer.
- 7) Run tubing with bit and clean out to T. D.
- 8) Pull tubing and bit.
- 9) Set casing and set packer.
- 10) Set packer and inhibited fluid.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE District Production DATE 7-15-69

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT DATE JUL 18 1969

CONDITIONS OF APPROVAL, IF ANY: