

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE
(Other instructions on
reverse side)

Form approved
Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. NAME OF OPERATOR
Texaco Producing Inc.

2. ADDRESS OF OPERATOR
P. O. Box 728, Hobbs, NM 88240

3. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

4. LETTER, P. 330' from the South
990' from the East

5. ELEVATIONS (Show whether TP, RL, Cal. etc.)

30-025-12251

3163 DF

5. LEASE DESIGNATION AND SERIAL NO.

NM-10185

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

West Dollarhide
Drinkard Unit

8. FARM OR LEASE NAME

9. WELL NO.

33

10. FIELD AND POOL, OR WILDCAT

Dollarhide Tubb Drinkard

11. SEC., T., R., N., OR S.W. AND
SURVEY OR AREA

30-24S-38E

12. COUNTY OR PARISH 13. STATE

Lea

NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUGGESTED REPORT OF:

1. DRILLING

2. WELL OR ALTER DRIVING

3. WATER SAMPLING

4. DEEPENING WELL

5. CLOSING

6. MULTIPLE COMPLETION

7. PRODUCTION TESTS

8. ALTERING CASING

9. PLUGGING

10. ABANDON

11. DRILLING OF A WELL

12. REABANDONMENT

13. OTHER

14. PLUGGING

15. OTHER

(Note: Do not check results of sampling or production on Well
No. 12, unless it is a separate report on the Log form.)

16. If well is being drilled, deepened, or otherwise altered, give subsurface boundaries and measure, and give vertical depth for all markers and zones pertinent to the well.

- 1) Move in, rig up, install BCP.
- 2) Pull 2 3/8" IPC tbg.
- 3) TH w/workstring and circ. out 45' of sand on top of RBP.
- 4) Pull up and spot 100' cmt (class "H" + 2% CaCl) plug from 6125' to 6225' on top of RBP, TOH.
- 5) TH and set cmt retainer at 3500'. Squeeze 100 sacks cmt (Class "H" + 2% CaCl) below retainer. Pull up and spot 35' cmt on top of retainer. TOH.
- 6) GH and cut 5 1/2" csg @ 3200'. Pull 5 1/2" csg.
- 7) TH and spot 200' cmt (Class "H" + 2% CaCl) across 8 5/8" csg shoe (3100' to 3300') TOH.
- 8) GH and perforate 8 5/8" csg @ 1320' with 4 holes (.39).
- 9) TH and set cmt retainer at 1270'. Try to circ. cmt (Class "H" + 2% CaCl) up 8 5/8" - 13 3/8" annulus; 770 sx calc. w/20% excess.
- 10) Pull up and spot 35' cmt on top of retainer.
- 11) Spot 50' cmt (Class "H" + 2% CaCl) plug (0'-50').
- 12) Install dry hole marker and clean location.

18. I hereby certify that the foregoing is true and correct.

SIGNED

J. L. Browning

TITLE District Admin. Supervisor

DATE 10/21/86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

11-19-86

COMMITTEE OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

