

C. OF COPIES RECEIVED	
DISTRIBUTION	
NTA FE	
LE	
S.G.S.	
AND OFFICE	
PERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☐ GAS WELL ☐ OTHER- **Water Injection Well** **West Dollarhide Queen Sand Unit**

Name of Operator **Skelly Oil Company** **West Dollarhide Queen Sand Unit**

Address of Operator **P. O. Box 1351, Midland, Texas 79701**

Location of Well **UNIT LETTER M 990 FEET FROM THE West LINE AND 330 FEET FROM**

THE **South** LINE, SECTION **30** TOWNSHIP **24S** RANGE **38E** NMPM. **Dollarhide Queen**

15. Elevation (Show whether DF, RT, GR, etc.) **3131' GR** 12. County **Lea**

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is in an area that has not responded to waterflood operations. In order to reduce operating expenses we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull tubing and packer.
- 2) Set 7" bridge plug at 3650'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1100-1560' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

*2-11-1973*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.  
SIGNED J. R. Avent TITLE Dist. Admin. Coordinator DATE March 4, 1973

APPROVED BY Joe M. Jolley TITLE Dist. Admin. Coordinator DATE March 4, 1973  
CONDITIONS OF APPROVAL, IF ANY: