

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved:
Budget Bureau No. 1001
Effective August 11, 1983

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER <u>Water Injection</u>	7. UNIT AGREEMENT NAME <u>West Dollarhide Queen Sand</u>
2. NAME OF OPERATOR <u>Sirgo Operating, Inc.</u>	8. FARM OR LEASE NAME <u>Unit</u>
3. ADDRESS OF OPERATOR <u>P.O. Box 3531, Midland, Texas 79702</u>	9. WELL NO. <u>32</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) <u>At surface</u> <u>Unit G, 1980 FNL 1650 FEL</u>	10. FIELD AND POOL OR WILDCAT <u>Dollarhide Queen</u>
14. PERMIT NO.	11. SEC., T., R., M., OR B.L. AND SURVEY OR AREA <u>Sec. 31, T24S R38E</u>
15. ELEVATIONS (Show whether DE, RT, GR, etc.)	12. COUNTY OR PARISH 13. STATE <u>Lea</u> <u>NM</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

☐ TEST WATER SHUT OFF	☐ PULL OR ALTER CASING
☐ FRACTURE TREAT	☐ MULTIPLE COMPLETION
☐ SHOOT OR ACIDIZE	☐ ABANDON*
☐ REPAIR WELL	☐ CHANGE PLANS
(Other)	

SUBSEQUENT REPORT OF:

☐ WATER SHUT OFF	☐ REPAIRING WELL
☐ FRACTURE TREATMENT	☐ ALTERING CASING
☐ SHOOTING OR ACIDIZING	☒ ABANDONMENT*
(Other)	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1-31-90 MI&RU plugging unit. POH w/tbg & pkr. RIH to 3620' w/5-1/2" CR, squeeze w/ 35 sx Class C, spot 5 sx on top. Spot 100' cmt plug @ 2570-2470'. Circ 10.2 brine mud to 1240'. Perf @ 1240'. Set CR @ 1140', squeeze w/30 sx Class C spot 5 sx on top. Circ 10.2 brine mud to 250'. Perf @ 250'. Bullhead 100 sx. Class C to surface. Install P&A marker.

18. I hereby certify that the foregoing is true and correct

SIGNED Bonnie Ottwater TITLE Production Technician

DATE 2-2-90

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 2-12-90

Signature not valid until
signature is completed.

*See Instructions on Reverse Side

RECEIVED