

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-12289
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name West Dollarhide Queen Sand Unit
8. Well No. 35
9. Pool name or Wildcat Dollarhide Queen
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☐ OTHER Water Injection

2. Name of Operator
Sirgo Operating, Inc.

3. Address of Operator
P.O. Box 3531, Midland, Texas 79702

4. Well Location
Unit Letter J : 1980 Feet From The South Line and 1650 Feet From The East Line

Section 31 Township 24S Range 38E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10-23-89 MI & RU pulling unit. Tbg parted @ 2799'.
10-24-89 Attempt to fish.
10-25-89 POH w/fish. Prepare to drill out iron sulfide.
10-26-89 RIH w/Mt bit to 3670'. SION.
10-27-89 Drill from 3670-3886', getting scale & iron sulfide in returns.
Circ. hole clean.
10-28/29-89 Shut In.
10-30-89 Set injection pkr @ 3500'. Start injecting @ 257 BWPD @ 1300# psi.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Bonnie Altwater TITLE Production Technician DATE 11-6-89

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

APPROVED BY

Orig. Signed by
Paul Kautz
Geologist

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NOV 13 1989

RECEIVED

NOV 9 1989

OCD
HOBBS OFFICE