

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-9311	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection	7. Unit Agreement Name West Dollarhide Drinkard Unit
2. Name of Operator Skelly Oil Company	8. Farm or Lease Name West Dollarhide Drinkard Unit
3. Address of Operator P. O. Box 1351, Midland, Texas 79701	9. Well No. 63
4. Location of Well UNIT LETTER L , 2130 FEET FROM THE South LINE AND 510 FEET FROM THE West LINE, SECTION 32 TOWNSHIP 24S RANGE 38E NMPM.	10. Field and Pool, or Wildcat Dollarhide Tubb-Drinkard
15. Elevation (Show whether DF, RT, GR, etc.) 3154' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Plug back and squeeze <input checked="" type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To confine injection to the main Drinkard and upper Abo Zones, we propose the following:

- 1) Move in workover rig and pull tubing and packer.
- 2) Clean out to 6848'.
- 3) Set cement plug from 6848' - 6750'.
- 4) Set bridge plug at 6345' and squeeze perforations 6086' - 6319'.
- 5) After cement has set, drill out cement plug and bridge plug.
- 6) Clean out to 6750'.
- 7) Run internally-coated tubing, set packer at approximately 6362', and return well to injection status.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>(Signed) D. R. Crow</u>	TITLE <u>Lead Clerk</u>	DATE <u>Dec. 2, 1971</u>
Orig. Signed by <u>Joe D. Roney</u>		
APPROVED BY <u>Joe D. Roney</u>	TITLE <u></u>	DATE <u>Dec 3 1971</u>
CONDITIONS OF APPROVAL, IF ANY: <u></u>		

RECEIVED

DEC 8 1971

OIL CONSERVATION COMM.
ROBBE, R. M.