

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Skelly Oil Company		West Dollarhide Queen Sand Unit
3. Address of Operator		9. Well No.
P. O. Box 1351, Midland, Texas 79701		43
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>0</u> , <u>990</u> FEET FROM THE <u>South</u> LINE AND <u>2310</u> FEET FROM		Dollarhide Queen
THE <u>East</u> LINE, SECTION <u>32</u> TOWNSHIP <u>24S</u> RANGE <u>38E</u> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3178' DF		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has not responded to waterflood operations. In order to reduce operating expenses, we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull rods, tubing and packer.
- 2) Set 5-1/2" bridge plug at 3660'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1000-1770' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED (Signed) J. R. Avent J. R. Avent TITLE Dist. Admin. Coordinator DATE March 4, 1973

APPROVED BY Orig. Signed by Joe D. Roney TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: