

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

C.L. CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
B-9613

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name West Dollarhide Queen Sand Unit
2. Name of Operator Sirgo-Collier, Inc.	8. Farm or Lease Name
3. Address of Operator P. O. Box 3531, Midland, Texas 79702	9. Well No. 26
4. Location of Well UNIT LETTER D, 990 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 32, TOWNSHIP 24S, RANGE 38E, N.M.P.M.	10. Field and Pool, or Wildcat Dollarhide Queen
15. Elevation (Show whether DF, RT, GR, etc.) 3172' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

2-16-88 Move in and rig up Baber Well Servicing. Pull and lay down rods and stand back tubing. Run in hole with casing scraper to 3600'.

2-18-88 Pick up 5-1/2" cement retainer and run in hole to 3550' and squeeze with 35 sx of cement. Pull out of retainer and spot 5 sx of cement on top. Pull up hole to 1800' and spot 25 sx of cement. Pull out of hole. Rig up wireline, go in hole and perforate 5-1/2" casing @ 1240'. Pick up 5-1/2" cement retainer and run in hole to 1147' and set. Squeeze with 50 sx cement. Pull out of retainer and spot 5 sx on top. Rig up wireline, go in hole and perforate 5-1/2" casing @ 360'. Bullhead squeeze with 140 sx of cement circulated to surface. Cut wellhead off, install P&A marker. Rig down and move off.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Amy L. Whitley TITLE Agent DATE March 1, 1988

APPROVED BY [Signature] TITLE OIL & GAS INSPECTOR DATE MAR 22 1988

CONDITIONS OF APPROVAL, IF ANY:

8

RECEIVED

MAR 2 - 1988

**OCD
HOBB'S OFFICE**