

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIP
(Other instruction
reverse side)DATE
reForm approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 03255 (f)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Stuart

9. WELL NO.

6

10. FIELD AND POOL, OR WILDCAT

Justis

11. SEC., T., R., M., CR BLK. AND
SURVEY OR AREA

Sec. 11-25S-37E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3170

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Squeeze, Perf. & Frac

PULL OR ALTER CASING

MULTIPLE COMPLET

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other) Squeeze, Perf. & Frac

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recore Log Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work).*

Squeezed perfs w/200 sacks. Tested squeezed perfs w/3000# for 15 mins, no decrease in pressure. Perf Upper Tubb-Drinkard w/1 jet @ 5852,56,82, 5025,31,38,48,60,69, & 80. Acidized w/840 gal. Frac w/10,000 gal 9# brine water & 15,000# sand. Mixed 1000# rock salt in 24 bbls brine followed w/500 gal. acid and 2nd stage of 10,000 gal frac.

Set packer w/expendable plug @ 5695'. Perf Blinebry w/1 jet @ 5114,24,28,38,46,50, 60,76,84, 5204,08,14,24,34,42,54,66,75,82, 5313,73, 5407,13,18,31,40,61,90, 5530,40, 57,69,96, 5612,22,30,58,76.

Frac Blinebry perfs w/20,000 gal 9# brine water & 30,000# sand. Pumped 48 bbls. brine water w/3000# rock salt, 500 gal. acid & frac w/20,000 gal. brine water & 30,000# sand. Pumped 24 bbls. brine water w/1500# rock salt & 500 gal. acid & frac w/20,000 gal. brine water, 30,000# sand. Pumped 24 bbls. brine water w/1500# rock salt & 500 gal. acid, frac w/20,000 gal. brine water, 30,000# sand.

Ran Blinebry & Tubb-Drinkard tubing and put back on production.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Drlg. Supt.

DATE 6-25-69

(This space for Federal or State office use)

APPROVED BY

TITLE

APPROVED

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side
J. L. GORDON
ACTING DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.