South Mattix Unit Federal Well #15 Unit A, 660' FNL & 660' FEL, Section 22, T-24-S, R-37-E Lea County, New Mexico Silurian Formation Proposed Re-Completion Procedure

- 1. MIRU Service Rig.
- 2. POOH with 2 7/8" tubing.
- 3. RIH and set a CIBP at 7345', dump 35' of cement on top of CIBP.
- 4. Rig up perforators and perf the Silurian zone at 4 DP JSPF, 90 degree phasing; interval to be perforated is 7002 to 7040'.
- 5. RIH with tubing and packer. Acidize Silurian with 1000 gallons of 15% HCL acid + ball sealers.
- 6. Rig out/move off, put well on production.