

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.  
LEASE DESIGNATION AND SERIAL NO.

NM-10934

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER  
2. NAME OF OPERATOR  
TEXACO Inc.  
3. ADDRESS OF OPERATOR  
P.O. Box 728 Hobbs, New Mexico 88240  
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface 660' FWL & 2080' FNL of Section 35, T-24-S,  
R-37-E, Unit Letter 'E', Lea County, New Mexico

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

C.C. Fristoe 'A' Fed NCT-1

9. WELL NO.

10

10. FIELD AND POOL, OR WILDCAT

Justis Blinebry

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec 35, T-24-S, R-37-E

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3200' (DF)

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

<input type="checkbox"/>
<input type="checkbox"/>
<input checked="" type="checkbox"/>
<input type="checkbox"/>

PULL OR ALTER CASING

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Rig up. Install BOP.
2. Set RBP @ 5150' & dump sand on plug.
3. Load hole and test. Log well.
4. Perforate 2-7/8" csg above top of cement w/2 jet shots.
5. Set cement retainer above perforations & squeeze w/1000 sx Class 'C' cement containing 10# salt per sack.
6. Drill out cement. Test csg. Pull RBP.
7. Acidize perforations 5208'-5707' w/1500 gal 15% NE Acid in 3-equal stages using 20 ball sealers between stages. Flush w/20 bbls fresh water.
8. Install producing equipment. Test & return to production.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Asst. Dist. Supt.

DATE 9-27-77

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

OCT - 4 1977

OIL CONSERVATION COMM.  
HOBBS, N. M.