

Humphrey Queen Unit #13
Plug and Abandon

Procedure:

1. MIRU Workover Rig. Tag CIBP at +/- 3250'. Spot 35' of cement on top.
2. RIH with tubing and tag cement plug. Circulate hole with 10 # Brine And gel.
3. ~~Spot cement plug from 250' to 2400'.~~ PERF @ 12,251' 50' OUTSIDE BRING CEMENT UP TO 972'-TAG
4. ~~Spot cement plug from 250' to 2400'.~~ Spot 10 sacks surface plug.
5. Cut casing and cap well.
6. Set dry hole marker and clean location.