

- 15) Set 10 sack cement plug 5800-5900'.
- 16) Set 10 sack cement plug 5015-5115'.
- 17) Set 10 sack cement plug 4206-4306'.
- 18) Set 10 sack cement plug 2650-2750'.
- 19) Set 10 sack cement plug 1307-1407'.
- 20) Set 10 sack cement plug surface-100'.
- 21) Installed dry hole marker 1-14-76.

The 8-5/8" OD and 5-1/2" OD casing were left in place. All intervals not cemented were filled with 10# mud.

RECEIVED

JAN 2 1977

OIL CONSERVATION COMM.
HOBBS, N. M.