

Submit 3 Copies To Appropriate District  
Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Avenue, Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103

Revised March 25, 1999

<b>WELL API NO.</b> 30-025-32773	
<b>5. Indicate Type of Lease</b> STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>	
<b>6. State Oil &amp; Gas Lease No.</b>	
<b>7. Lease Name or Unit Agreement Name:</b> West Dollarhide Drinkard Unit	
<b>8. Well No.</b> 150	
<b>9. Pool name or Wildcat</b> Dollarhide, Tubb, Drinkard	
<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
<b>1. Type of Well:</b> Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other	
<b>2. Name of Operator</b> Chevron USA, Inc.	
<b>3. Address of Operator</b> 15 Smith Rd. Midland, Tx 79705	
<b>4. Well Location</b> Unit Letter <u>P</u> : <u>650</u> feet from the <u>south</u> line and <u>540</u> feet from the <u>east</u> line Section <u>31</u> Township <u>24-S</u> Range <u>38-E</u> NMPM County <u>Lea</u>	
<b>10. Elevation (Show whether DR, RKB, RT, GR, etc.)</b>	

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

1. Set 5 1/2 CIBP @ 6275 spot 25sx fr/6275-6075(Drinkard)Tag @ 6035
2. Displace hole w/MLF 9.5# Brine w/25 # Gel P/BBL.
3. Spot 25sx plug fr/3800-3600(Queen)
4. Spot 25sx plug fr/2600-2400(B-salt,Yates)Tag @ 2366
5. Spot 25sx plug fr/1200-1000(8 5/8 shoe,T-salt)Tag @ 981
6. Perf 4 holes @ 275 sqz perf w/135sx fr/275 to surf 5 1/2 X 8 5/8 (surf) Tag @ surf
7. Install dry hole marker 12-13-02

Approved as to Plugging of the Well Bore.  
Liability under bond is retained until  
Surface restoration is completed.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE MANAGER / SUNSET DATE 12-13-02

Type or print name Jimmy BAGLEY Telephone No. 9155208756

(This space for State use)

APPROVED BY [Signature] TITLE [Signature] DATE DEC 19 2002

Conditions of approval, if any: