

ATTACHMENT TO FORM 3160-5  
BTA OIL PRODUCERS

VACA DRAW, 9418 JV-P, #1

Deepen to 14,200' for Wolfcamp Completion:

21. When TD is reached, run open hole logs as directed.
22. If well is productive, run and cement 2-7/8" tbg. Top of cement to be @  $\pm 11,500'$ .
23. Remove BOP's and install 10,000 psi WP X-mas tree. Test tree.
24. Rig down and move out drilling equipment.
25. Hook-up Test equipment.
26. Perforate as directed.
27. Flow test well.
28. Stimulation program to follow.