

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
310 Old Santa Fe Trail, Room 206  
Santa Fe, New Mexico 87503

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Langlie Federal Brine Well
8. Well No. 1
9. Pool name or Wildcat
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Brine Well
2. Name of Operator William H. Brininstool dba Salado Brine Well
3. Address of Operator P. O. Drawer A Jal, NM 88252
4. Well Location Unit Letter <u>P</u> : <u>115.3</u> Feet From The <u>South</u> Line and <u>728.3</u> Feet From The <u>East</u> Line Section <u>14</u> Township <u>25S</u> Range <u>37E</u> NMPM <u>Lea</u> County <u></u>

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

3-15-95 Ran 5 1/2 inch cast Iron Bridge Plug on wireline, set at 900 feet from surface. Ran 2 7/8 inch tubing in hole and tag plug, pull up 3 inches. Pump cement, circulate to surface. Pull tubing out of hole, pumped cement down casing fill to surface. Place dry hole marker in top of casing. Cleaned location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Christine Brininstool TITLE Office Manager DATE 3-23-95

TYPE OR PRINT NAME Christine Brininstool TELEPHONE NO. 505-395-2010

(This space for State Use)

APPROVED BY Charlie Perrin TITLE OIL & GAS SUPERVISOR DATE SEP 02 1995

CONDITIONS OF APPROVAL, IF ANY:

**RECEIVED**

MAY 14 1964

UCL LIBRARY  
OFFICE