

Procedure Continued  
Cooper Jal Unit Well No. 126

Page -2-

- 13.) MI-RU. Pull rods and pump. Install BOP.
- 14.) TOH with production tubing. TIH with bit, drill collars and workstring.
- 15.) Drill out CIBP at 3370'. Tag PBTD. TOH with workstring, drill collars and bit.
- 16.) TIH with production tubing, rods and pump. Return to production.