P. O. I...

Form Approved.

UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY	5. LEASE NM 7488 6. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)	_ B. FARM OR LEASE NAME
1. oil gas well other 2. NAME OF OPERATOR Sun Exploration & Production Co.	Courtland Meyers 9. WELL NO. 1
 3. ADDRESS OF OPERATOR P.O. Box 1861, Midland, Tx. 79702 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.) AT SURFACE: Ut.Ltr.J 1970 FSL & 1980 FEL 	Sec. 6, 1-24-5, R-37-E
AT TOP PROD. INTERVAL: AT TOTAL DEPTH: 16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	12. COUNTY OR PARISH 13. STATE Lea New Mexico 14. API NO.
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL PULL OR ALTER CASING MULTIPLE COMPLETE CHANGE ZONES ABANDON* (other)	15. ELEVATIONS (SHOW DF, KDB, AND WD) 3316 GR OF LAND (NOTE: Report result of multiple completion change on Form 6-00s) 1983
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state including estimated date of starting any proposed work. If well is dimeasured and true vertical depths for all markers and zones pertinent MIRU WO rig. POH w/rods and pump. Install BOP. POH RIH w/RBP on 2-3/8" WS. Set RBP at 3400'. POH w/WS pailer. RIH w/Baker FB pkr. Set at 2975'. EIR into perfs 30 RIH w/cmt.ret. and WS. Set cmt. ret. at + 3055. Square form injection test.	e all pertinent details and will be thent dates, irectionally drilled, give subsurface locations and it to this work.)* W/tbg and Baker AD-1 pkr. Dump 10' sand on RBP w/WL dump

rom injection test. POH w/WS. SIFN. RIH w/6-1/8" bit, 6-4-3/4"DC's, and WS. DO cmt. ret. and cmt. POH w/WS, DC's, &bit. RIH w/ FB pkr and WS. Set pkr at 3000'. Test sqz to 500 psi. Swab test well for FE.

POH w/ WS and pkr. Re-sqz. if necessary. CO sand on top of RBP w/ hydrostatic bailer or circulate. Retrieve RBP and POH. Contact Hollis Cox w/Getty (phone #505-395-2545). RIH w/2-7/8" production string, rod string, and pump as per Getty instructions. Put on pump.

		• •		
Subsurface Safety Valve: Manu. and Ty	pe		Set @	. Ft.
18. I hereby certify that the foregoing is	s true and correct			
18. I hereby certify that the foregoing is	TITLE Sr. Acct	g. Assist date <u>Nov</u>	. 1, 1983	
	(This space for Federal or			
APPROVED BY	TITLE	DATE		
		A	CCEPTED FOR RE	CORD

see Instructions on Reverse Side

3 1983 NOV