

- (16) Run Baker A-2 Lockset packer on 2 3/8" tubing with seating nipple below packer.
- (17) Leave packer swinging at 3400' and swab test off.
- (18) Set packer at approximately 3400'.
- (19) Run pump and rods and place well on production pumping the Queen and flowing the Jalmat out the tubing casing annulus.

RECEIVED

FEB 28 1978

OIL CONSERVATION COMM.  
HOBBS, N. M.