

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b>		7. Unit Agreement Name <b>Myers Langlie-Mattix U.</b>
2. Name of Operator <b>Skelly Oil Company</b>		8. Farm or Lease Name <b>Myers Langlie-Mattix U.</b>
3. Address of Operator <b>P. O. Box 1351, Midland, Texas 79701</b>		9. Well No. <b>194</b>
4. Location of Well UNIT LETTER <b>A</b> , <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>330</b> FEET FROM THE <b>East</b> LINE, SECTION <b>9</b> , TOWNSHIP <b>24S</b> , RANGE <b>37E</b> , N.M.P.M.		10. Field and Pool, or Wildcat <b>Langlie-Mattix</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3277' KB</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <b>Convert to Injection</b> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Move in workover rig. Pull tubing.
- 2) Clean out to minimum of 3554'.
- 3) Set coated injection tubing and packer at  $\pm$  3470'. Load tubing - casing annulus with treated water.
- 4) Place well on active injection status, injecting water thru Langlie-Mattix perms. 3505-3554'.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

(Signed) D. R. Crow

SIGNED <b>D. R. Crow</b>	TITLE <b>Lead Clerk</b>	DATE <b>Oct. 31, 1975</b>
Orig. Signed by <b>Jerry Sexton</b>		
APPROVED BY <b>Dist. 1, Supv.</b>	TITLE	DATE <b>NOV 5 1975</b>

CONDITIONS OF APPROVAL, IF ANY: