South Mattix Unit Federal Well No. 21 Letter K, Section 15, T-24-S, R-37-E API No. 30-025-21873 Lea County, NM

3/23/2000 - 4/5/2000

MI x RU. Install BOP. POOH with injection tubing and packer. Attempt to drill at 5368' but could not get good circulation. Run 4-3/4" bit x bulldog bailer and tag what seems like fill at 5368'. Clean scale off casing walls down to 5678'. Spot 100 sx. PP cement across Yeso perfs (5105' - 5642'). Squeeze 500 sx. PP Neat cement into perforations. WOC. Drill cement from 4701' to 5290'. Circulate clean and recover possible pieces of casing. Drill from 5290' - 5343'. Getting more metal back at 5340'. Estimate bad casing from 5290' - 5340'. Make decision to cease operations and hold well for further evaluation. LD all tubing x drill collars, ND BOP, install wellhead, RD x MO.

÷

GEAESEC

7030 V58 2r ♥ 10: 5J



Ren Ward