



## BLOWOUT PREVENTER DIAGRAM

### CLOSING METHOD

Sufficient accumulator volume shall be available to operate both the bag type preventer and pipe ram preventer with a snap-action through the following steps: close-open-close.

— SERIES 900 —