ANNULAR PREVENTOR
TO BE USED AS DIVERTOR ONLY

— FLOW LINE

STARTING HEAD