

- 6. All connections to and from preventer to have a pressure rating equivalent to that of the B.O.P.'s.
- 7. Inside blowout preventer to be available on rig floor.
- 8. Operating controls located a safe distance from the rig floor
- 9. Hole must be kept filled on trips below intermediate casing. Operator not responsible for blowouts resulting from not keeping hole full.
- 10. D. P. float must be installed and used below zone of first gas intrusion.

•