## BLOWOUT PREVENTER

TER DIAGRAM



## CLOSING METHOD

Sufficient accumulator volume shall be available to operate both the bag type preventer and pipe ram preventer with a snap-action through the following steps: close-open-close.