
HUBBS DIVISION CLASS III PREVENTER



BARREL OF THE RAM PREVENTER

GENERAL INSTRUCTIONS ON PAGE FOLLOWING FIGURE III-7