7.6.2 Function Test Frequency

到

J

J

]

3

J

J

All rams, annulars, valves, and other items specified below, shall be function tested at the following frequencies.

- (1) On initial installation from driller control and remote panel.
- (2) Each trip out of hole alternating between driller's and remote control panel but not more than once every twenty-four (24) hours. Close pipe rams or annular preventer ONLY on drill pipe.
- 7.6.3 Test Pressures

Use the following table to identify which test is appropriate and at what pressure.

TEST	DESCRIPTION
Low Pressure	Test to 200-300 psi prior to each high pressure test.
Initial Installation	Test all rams, annulars, valves, choke manifold, kelly cocks, and safety valves to the lesser of the following pressures.
	. Rated working pressure of the component in the blowout preventer assembly with the exception of annular preventer which is to be tested to 70% of the rated working pressure.
	. The API rated casing burst pressure of the last casing to be utilized in the well with the BOP assembly being tested.
	. Rated working pressure of the casing head.
	. If "Cup Tester" is used do not exceed 80% of the API rated burst pressure of the casing.
Repair	Repaired or replaced components are to be tested to the same pressures used in the Initial Test.