




EXHIBIT "B"
DEPCO, Inc.
No. 1 Sundance Federal
1980' FS & EL
Sec. 3-T12S-R30E
Chaves Co., New Mexico

Mile Marker
24

LOCATION

MILEAGE LOG: Distances shown are computed over Controlled Access Highways wherever feasible. To find the mileage between two points, refer to the numbers assigned to these points. In the listing under the lower number of the two, the mileage is given opposite the number assigned to the other. For example: bad (4) to Santa Fe (17) is 263 miles (under grouping 4 mi. opposite 17).

1. Alamogordo	2-800	22-236	21-145	21-046	22-234	7-314	10-324	15-320	21-257	15-361	12	19
2. Albuquerque	3-110	2	22-177	22-500	5	6-403	12-44	17-202	22-317	17-308	14-406	15-306
3. Artesia	4-144	3-238	3	4	6-167	10-299	14-182	18-301	10	18-223	16-183	15-17
4. Carlsbad	5-346	4-272	4-34	5-344	7-432	11-127	15-434	20-224	11-304	18-277	17-65	18-306
5. Clayton	6-228	5-278	5-310	6-184	8-387	11-127	15-434	20-224	12-341	20-302	18-64	20-48
6. Clovis	7-96	6-220	6-180	7-185	9-418	12-296	16-203	21-328	13-207	21-323	18-196	21-37
7. El Paso, Tex.	8-383	7-283	7-198	8-455	10-357	13-193	17-307	22-360	22-300	20-75	22-17	22-17
8. Farmington	9-332	8-183	8-421	9-412	11-294	14-414	16-263	18-308	21-873	21-873	22-107	22-107
9. Gallup	10-201	9-140	9-378	10-351	12-414	15-234	19-192	21-301	18-278	12	17	17
10. Grants	11-187	10-78	10-317	11-60	13-150	16-111	20-377	10-61	17-142	13-308	14-106	15-106
11. Hobbs	12-68	11-315	11-77	12-208	14-332	17-214	21-118	11-435	18-197	14-116	14	14-128
12. Las Cruces	13-241	12-219	12-178	13-866	15-85	18-108	22-322	12-341	19-132	16-116	15-307	16-127
13. Las Vegas	14-186	13-125	13-232	14-327	16-271	19-348	22-360	13-268	20-212	18-185	20-264	20-264
14. Lordsburg	15-348	14-278	14-226	15-378	17-215	21-320	22-360	14-303	21-267	18-185	21-27	21-27
15. Raton	16-117	15-229	15-330	16-73	17-215	21-320	22-360	15-309	22-256	17-282	17-341	22-107
16. Roswell	17-221	16-190	16-38	17-363	18-109	22-83	23-103	18-138	17-903	18-148	18-207	17
17. Santa Fe	18-177	17-63	17-329	18-302	19-336	20-183	21-412	19-446	13-267	18-193	21-74	21-133
18. Santa Rosa	19-129	18-118	18-168	19-334	20-183	21-412	22-110	14-428	18-193	13-287	21-74	21-133
19. Socorro	20-291	19-71	19-200	20-333	21-412	22-110	23-103	19-446	18-193	13-287	21-74	21-133
20. Truth or Consequences	21-136	20-183	20-307	21-890	22-110	23-103	24-128	19-446	18-193	13-287	21-74	21-133
21. Tucumcari												
22. Tucumcari												

THE INTERSTATE SYSTEM

- ONE AND TWO-DIGIT SIGNS
- Even numbers are east-west routes
 - Odd numbers are north-south routes
- THREE-DIGIT SIGNS
- First digit even: route through or around a city
 - First digit odd: spur into a city

RECEIVED

MAR 30 1978

OIL CONSERVATION COMM.
HOBBS, N. M.